

On Demand Brings the Video Store to You


Access hundreds of shows and movies – anytime. You can reach **On Demand** from the **Quick Menu** or **Main Menu**, or from the **Flip Bar**, if available.



With **On Demand**¹ you can find free content or rent movies and programs from the On Demand library. Watch shows at your convenience, as many times as you like within the rental period. You can even pause, fast-forward, rewind, or record so you can watch when you are ready. Enjoy shows, movies, music videos and more on your schedule.

Pay-Per-View (PPV) Made Easy

Ordering PPV¹ movies and events is easy with i-Guide. From the **Quick Menu**² or **Main Menu**,² select the **PPV** option to see a list of available programs. Use your remote to get detailed information, watch a preview and place an order.



Enhance Your Digital Cable Experience

With i-Guide, it's easy to find and watch the programs you love. Enhanced search capabilities and new DVR recording management tools let you enjoy your favorite shows any time.

Remote Control Features


Basic Navigation

- It's easy to get started. Press the **GUIDE** button on your remote to access the Listings By Time grid.
- Blue** is always the highlight color. As you navigate listings, the highlight appears on screen to indicate the current selection.
- Press the **Left**, **Right**, **Up**, or **Down** arrows to move the highlight.
- Press **OK/SELECT** to tune to a show or to access program information.
- Press the **EXIT** button to return to watching TV.



Digital Video Recording

Pause live television. Rewind and replay programs. Record your favorites all season long. With **DVR**¹ you're in control from the comfort of your own home. And with dual-tuner DVR, you can watch one program while recording another.





DVR Puts You In Control

Build Your Own Personal Video Library

It's easy to record with i-Guide. Press **REC** on your remote any time while watching TV for easy one-touch recording. Press **OK/SELECT** from the **Program Info** screen or from the guide listings to set up a one-time or series recording, or to set up an auto-recording from any **Search** results screen.

Your Recordings

i-Guide makes it easy to manage your recordings. Access the **DVR Menu** from **DVR** on the **Quick Menu** or **Main Menu**. From here, select **My Recordings** to view your list.



Series recordings are automatically grouped into **Folders** so you can quickly scroll through your list. Use the **Up** or **Down** arrows to select a series and then press **OK/SELECT**. Scroll through the list to find the episode you want.

Control Live TV

Any time you tune to a channel the DVR starts a temporary recording so you can **PAUSE** if the phone rings, **REWIND** the scene you missed, and **FAST-FORWARD** to skip what you don't want to watch.



DVR Cleanup lets you delete multiple shows at once, while **DVR History** keeps track of shows that were deleted. i-Guide makes it simple to organize your shows so you can enjoy watching on your schedule.



Inside i-Guide[®]


HD

Quick Reference Guide




Quick Menu: Quick & Easy

The **Quick Menu**² offers shortcuts to key i-Guide features. Just press **MENU** on your remote while you are using the guide or watching TV. You'll have easy access to your **DVR**, **On Demand**, **HD** programs, **Search** features, and **Parental Controls**.



Press the **◀ ▶** arrows on your remote to highlight an option, press **OK/SELECT** and you're on your way.


All Access With Main Menu



From the **Main Menu**,² you can access all i-Guide features. Press **MENU** twice, then select from the options, including **Listings By Time**, **Search**, **DVR**, **Local Weather**, **Setup**, and more.

Listings By Time

Press **GUIDE** to access **Listings By Time**. Channel numbers and network call letters appear in the left column; program times along the top. Use **◀ ▶ ▲ ▼** arrows to navigate the channel lineup or to look ahead at upcoming shows.




Color coding makes it easy:
Gray – Regular programs
Purple – Movies

Green – Sports
Light Blue – Kids' programs


Mini Guide

The **Mini Guide** lets you watch television and view listings without leaving your program. To access the Mini-Guide, press **OK/SELECT**, then use the **◀ ▶** arrows to browse time periods and the **▲ ▼** arrows to browse channels.




Instant Program Info

i-Guide provides **Instant Information** while you view program listings, including titles, start and end times, a brief description, and content ratings. Helpful indicators identify settings such as **Reminders**, **Recordings**, **Locks** and **Favorites**.



Action Icons


From the **Listings By Time** grid press **INFO** to learn more about a program. Use the **Action Icons** at the bottom to set **Recordings**, **Reminders**, **Parental Controls** and more.



Use the arrow **◀ ▶** buttons to highlight an icon.



Go Ahead, Play Favorites

Create up to four **Favorites** lists – one for everyone in the family. Select **♥** from the **Quick Menu**, or **My Favorite Channels** from the **Main Menu**.



Enhanced Searching


i-Guide offers expanded search capabilities so you can find your favorite shows faster and discover new ones. Search by **Category** or by **Title**, **Keyword**, or **Actor/Director**. With new integrated search, include **TV Listings**, **On Demand**, **Pay-Per-View**, and **DVR** options in your search results. Access Search from the **Quick Menu** or from the **Main Menu**.




To search by **Title**, **Keyword**, or **Actor/Director**, simply use the on-screen keyboard to spell out a title, topic, or name. i-Guide will display a list of matching shows. You can select **Save Search** or set an **Auto-Recording** right from any **Search** results screen.

Parental Controls

Parental Controls allow you to restrict viewing and purchases of TV programs based on your preferences. Set a personalized 4-digit PIN to place locks on selected movie & TV ratings, TV content ratings, channels and titles. You can also hide adult titles from displaying on the screen.



Select **🔒** from the Quick Menu to set up Parental Controls and PINs.



Smart Channel Surfing



The **Flip Bar** displays program information when you change channels and lets you tune easily to On Demand programs or HD channels. You can configure **HD Auto Tune** so i-Guide will automatically tune to an available HD channel³. Press **INFO** for program details.

¹ PPV, On Demand and DVR not available in all areas. On Demand programs may not be recorded with DVR.
² Menu selections vary depending on the services your cable provider offers.
³ HD programming is not available in all areas or for all channels. See your cable provider for details.